


# Prática 5

ADC

# ADC

- ESP32 integrates two 12-bit SAR ADCs.
- It is also possible to measure internal signals, such as vdd33.



# ADC

- Two SAR ADCs, with simultaneous sampling and conversion
- Up to 18 analog input pads
- 12-bit, 11-bit, 10-bit, 9-bit configurable resolution
- DMA support (available on one controller)
- Multiple channel-scanning modes (available on two controllers)
- Operation during deep sleep (available on one controller)

# ADC

- The ESP32 integrates 2 SAR (Successive Approximation Register) ADCs, supporting a total of 18 measurement channels (analog enabled pins).
- These channels are supported:
- ADC1:
  - 8 channels: GPIO32 - GPIO39
- ADC2:
  - 10 channels: GPIO0, GPIO2, GPIO4, GPIO12 - GPIO15, GPIO25 - GPIO27

```
/-----ADC1 Init-----//
adc_oneshot_unit_handle_t adc1_handle;
adc_oneshot_unit_init_cfg_t init_config1 = {
    .unit_id = ADC_UNIT_1,
};
adc_oneshot_new_unit(&init_config1, &adc1_handle);

//-----ADC1 Config-----//
adc_oneshot_chan_cfg_t config = {
    .bitwidth = ADC_BITWIDTH_DEFAULT,
    .atten = EXAMPLE_ADC_ATTEN,
};
adc_oneshot_config_channel(adc1_handle, EXAMPLE_ADC1_CHAN0, &config);

//-----ADC1 Calibration Init-----//
adc_cali_line_fitting_config_t cali_config = {
    .unit_id = ADC_UNIT_1,
    .atten = EXAMPLE_ADC_ATTEN,
    .bitwidth = ADC_BITWIDTH_DEFAULT,
};

adc_cali_create_scheme_line_fitting(&cali_config, &handle);
```

## adc\_oneshot\_new\_unit

```
esp_err_t adc_oneshot_new_unit(const adc_oneshot_unit_init_cfg_t *init_config,  
                               adc_oneshot_unit_handle_t *ret_unit)
```

Create a handle to a specific ADC unit.

### Note

This API is thread-safe. For more details, see ADC programming guide

- Parameters:**
- **init\_config** – [in] Driver initial configurations
  - **ret\_unit** – [out] ADC unit handle
- Returns:**
- ESP\_OK: On success
  - ESP\_ERR\_INVALID\_ARG: Invalid arguments
  - ESP\_ERR\_NO\_MEM: No memory
  - ESP\_ERR\_NOT\_FOUND: The ADC peripheral to be claimed is already in use
  - ESP\_FAIL: Clock source isn't initialised correctly

```
struct adc_oneshot_unit_init_cfg_t
```

ADC oneshot driver initial configurations.

### Public Members

**adc\_unit\_t unit\_id**

ADC unit.

**adc\_oneshot\_clk\_src\_t clk\_src**

Clock source.

**adc\_ulp\_mode\_t ulp\_mode**

ADC controlled by ULP, see [adc\\_ulp\\_mode\\_t](#)

## adc\_oneshot\_config\_channel

```
esp_err_t adc_oneshot_config_channel(adc_oneshot_unit_handle_t handle, adc_channel_t channel,  
const adc_oneshot_chan_cfg_t *config)
```

Set ADC oneshot mode required configurations.

### Note

This API is thread-safe. For more details, see ADC programming guide

- Parameters:
- **handle** – [in] ADC handle
  - **channel** – [in] ADC channel to be configured
  - **config** – [in] ADC configurations

- Returns:
- ESP\_OK: On success
  - ESP\_ERR\_INVALID\_ARG: Invalid arguments

```
struct adc_oneshot_chan_cfg_t
```

ADC channel configurations.

### Public Members

```
adc_atten_t atten
```

ADC attenuation.

```
adc_bitwidth_t bitwidth
```

ADC conversion result bits.

# ADC Attenuation

The ESP32 ADCs can measure analog voltages from 0 V to  $V_{ref}$ .

Among different chips, the  $V_{ref}$  varies, the median is 1.1 V.

In order to convert voltages larger than  $V_{ref}$ , input voltages can be attenuated before being input to the ADCs.

There are 4 available attenuation options, the higher the attenuation is, the higher the measurable input voltage could be.

Attenuation	Measurable input voltage range
ADC_ATTEN_DB_0	100 mV ~ 950 mV
ADC_ATTEN_DB_2_5	100 mV ~ 1250 mV
ADC_ATTEN_DB_6	150 mV ~ 1750 mV
ADC_ATTEN_DB_11	150 mV ~ 2450 mV

Atenuação				
11	6	2,5	0	
3,55	2,00	1,33	1	
3,9 V	2,2 V	1,5 V	1,1 V	



# Exemplo

```
while (1) {  
  
    adc_oneshot_read(adc1_handle, EXAMPLE_ADC1_CHAN0, &adc_raw[0][0]);  
  
    if (do_calibration1) {  
        adc_cali_raw_to_voltage(adc1_cali_handle, adc_raw[0][0], &voltage[0][0]);  
    }  
  
    adc_oneshot_read(adc2_handle, EXAMPLE_ADC2_CHAN0, &adc_raw[1][0]);  
    if (do_calibration2) {  
        adc_cali_raw_to_voltage(adc2_cali_handle, adc_raw[1][0], &voltage[1][0]);  
    }  
  
    vTaskDelay(pdMS_TO_TICKS(1000));  
}
```

## adc\_oneshot\_read

```
esp_err_t adc_oneshot_read(adc_oneshot_unit_handle_t handle, adc_channel_t chan, int *out_raw)
```

Get one ADC conversion raw result.

### Note

This API is thread-safe. For more details, see ADC programming guide

### Note

This API should NOT be called in an ISR context

- Parameters:**
- **handle** – [in] ADC handle
  - **chan** – [in] ADC channel
  - **out\_raw** – [out] ADC conversion raw result

- Returns:**
- ESP\_OK: On success
  - ESP\_ERR\_INVALID\_ARG: Invalid arguments
  - ESP\_ERR\_TIMEOUT: Timeout, the ADC result is invalid

## adc\_cali\_raw\_to\_voltage

```
esp_err_t adc_cali_raw_to_voltage(adc_cali_handle_t handle, int raw, int *voltage) 
```

Convert ADC raw data to calibrated voltage.

- Parameters:**
- **handle** – [in] ADC calibration handle
  - **raw** – [in] ADC raw data
  - **voltage** – [out] Calibrated ADC voltage (in mV)

- Returns:**
- ESP\_OK: On success
  - ESP\_ERR\_INVALID\_ARG: Invalid argument
  - ESP\_ERR\_INVALID\_STATE: Invalid state, scheme didn't registered

# Referências

- [https://www.espressif.com/sites/default/files/documentation/esp32\\_technical\\_reference\\_manual\\_en.pdf](https://www.espressif.com/sites/default/files/documentation/esp32_technical_reference_manual_en.pdf)