

Prática 3

General Purpose Timer (GPTimer)

General Purpose Timer (GPTimer)

- The ESP32 chip contains two hardware timer groups. Each group has two general-purpose hardware timers.
- 4 general-purpose timers embedded in the ESP32.
- 64-bit generic timers based on 16-bit prescalers
- 64-bit auto-reload-capable up/down counters.

GPTimer

The timers feature:

A 16-bit clock prescaler, from 2 to 65536

A 64-bit time-base counter

Configurable up/down time-base counter: incrementing or decrementing

Halt and resume of time-base counter

Auto-reload at alarm

Software-controlled instant reload

Level and edge interrupt generation.

Fonte de clock APB




Table 3-4. Peripheral Clock Usage

Peripherals	APB_CLK	REF_TICK	LEDC_SCLK	APLL_CLK	PLL_D2_CLK
EMAC	Y	N	N	Y	N
TIMG	Y	N	N	N	N
I2S	Y	N	N	Y	Y
UART	Y	Y	N	N	N
RMT	Y	Y	N	N	N
LED PWM	Y	Y	Y	N	N
PWM	Y	N	N	N	N
I2C	Y	N	N	N	N
SPI	Y	N	N	N	N
PCNT	Y	N	N	N	N
eFuse Controller	Y	N	N	N	N
SDIO Slave	Y	N	N	N	N
SDMMC	Y	N	N	N	N

Table 3-5. APB_CLK Derivation

CPU_CLK Source	APB_CLK
PLL_CLK	80 MHz
APLL_CLK	CPU_CLK / 2
XTAL_CLK	CPU_CLK
RTC8M_CLK	CPU_CLK

Initialization

struct gptimer_config_t

General Purpose Timer configuration.

Public Members

gptimer_clock_source_t clk_src

GPTimer clock source

gptimer_count_direction_t direction

Count direction

uint32_t resolution_hz

Counter resolution (working frequency) in Hz, hence, the step size of each count tick equals to (1 / resolution_hz) seconds

int intr_priority

GPTimer interrupt priority, if set to 0, the driver will try to allocate an interrupt with a relative low priority (1,2,3)

uint32_t intr_shared

Set true, the timer interrupt number can be shared with other peripherals

struct gptimer_config_t::[anonymous] flags

GPTimer config flags

enum timer_count_dir_t

Decides the direction of counter.

Values:

TIMER_COUNT_DOWN = 0

Descending Count from cnt.high|cnt.low

TIMER_COUNT_UP = 1

Ascending Count from Zero

Initialization - example

```
gptimer_handle_t gptimer = NULL;
gptimer_config_t timer_config = {
    .clk_src = GPTIMER_CLK_SRC_DEFAULT,
    .direction = GPTIMER_COUNT_UP,
    .resolution_hz = 1 * 1000 * 1000, // 1MHz, 1 tick = 1us
};
ESP_ERROR_CHECK(gptimer_new_timer(&timer_config, &gptimer));
```

Set and Get Count Value

- When the GPTimer is created, the internal counter will be reset to zero by default
- The counter value can be updated asynchronously by `gptimer_set_raw_count()`
- Count value can be retrieved by `gptimer_get_raw_count()`, at any time.

Set up Alarm Action

struct gptimer_alarm_config_t

General Purpose Timer alarm configuration.

Public Members

uint64_t alarm_count

Alarm target count value

uint64_t reload_count

Alarm reload count value, effect only when `auto_reload_on_alarm` is set to true

uint32_t auto_reload_on_alarm

Reload the count value by hardware, immediately at the alarm event

struct gptimer_alarm_config_t::[anonymous] flags

Alarm config flags

```
esp_err_t gptimer_set_alarm_action(gptimer_handle_t timer, const gptimer_alarm_config_t *config)
```

Set alarm event actions for GPTimer.

Note

This function is allowed to run within ISR context, so that user can set new alarm action immediately in the ISR callback.

Note

If `CONFIG_GPTIMER_CTRL_FUNC_IN_IRAM` is enabled, this function will be placed in the IRAM by linker, makes it possible to execute even when the Flash Cache is disabled.

Parameters:

- **timer** - [in] Timer handle created by `gptimer_new_timer`
- **config** - [in] Alarm configuration, especially, set config to NULL means disabling the alarm function

Set up Alarm Action - Example

```
gptimer_alarm_config_t alarm_config2 = {  
    .reload_count = 0,  
    .alarm_count = 1000000,  
    .flags.auto_reload_on_alarm = true,  
};
```

```
ESP_ERROR_CHECK(gptimer_set_alarm_action(gptimer, &alarm_config2));
```

Register Event Callbacks

- hook your function to the interrupt service routine by calling `gptimer_register_event_callbacks()`
- The user data will be directly passed to the callback function.

```
struct gptimer_event_callbacks_t
```

Group of supported GPTimer callbacks.

Public Members

```
gptimer_alarm_cb_t on_alarm
```

Timer alarm callback

Register Event Callbacks

```
esp_err_t gptimer_register_event_callbacks(gptimer_handle_t timer, const gptimer_event_callbacks_t *cbs, void *user_data)
```

Set callbacks for GPTimer.

Note

User registered callbacks are expected to be runnable within ISR context

Note

The first call to this function needs to be before the call to `gptimer_enable`

Note

User can deregister a previously registered callback by calling this function and setting the callback member in the `cbs` structure to NULL.

- Parameters:**
- **timer** – [in] Timer handle created by `gptimer_new_timer`
 - **cbs** – [in] Group of callback functions
 - **user_data** – [in] User data, which will be passed to callback functions directly

Register Event Callbacks

```
static bool IRAM_ATTR example_timer_on_alarm_cb_v1(gptimer_handle_t timer, const gptimer_alarm_event_data_t
*edata, void *user_data)
{
    -----
}

gptimer_event_callbacks_t cbs = {
    .on_alarm = example_timer_on_alarm_cb_v1,
};
ESP_ERROR_CHECK(gptimer_register_event_callbacks(gptimer, &cbs, queue));
```

Enable and Disable Timer

- Before doing IO control to the timer, you need to enable the timer first, by calling `gptimer_enable()`.
 - Switch the timer driver state from init to enable.
 - Enable the interrupt service if it has been lazy installed by `gptimer_register_event_callbacks()`.
 - Acquire a proper power management lock if a specific clock source (e.g. APB clock) is selected.

Start and Stop Timer

- gptimer_start() can make the internal counter work,
- gptimer_stop() can make the counter stop working.

Example

```
gptimer_config_t timer_config = {  
    .clk_src = GPTIMER_CLK_SRC_DEFAULT,  
    .direction = GPTIMER_COUNT_UP,  
    .resolution_hz = 1000000, // 1MHz, 1 tick=1us  
};  
ESP_ERROR_CHECK(gptimer_new_timer(&timer_config, gptimer1));
```

```
gptimer_event_callbacks_t cbs = {  
    .on_alarm = example_timer_on_alarm_cb_v1,  
};  
ESP_ERROR_CHECK(gptimer_register_event_callbacks(gptimer, &cbs, queue));
```

ESP_ERROR_CHECK(gptimer_enable(gptimer));

```
gptimer_alarm_config_t alarm_config = {  
    .reload_count = 0,  
    .alarm_count = 1000000,  
    .flags.auto_reload_on_alarm = false,  
};  
ESP_ERROR_CHECK(gptimer_set_alarm_action(gptimer, &alarm_config));
```

ESP_ERROR_CHECK(gptimer_start(gptimer));

Referências

- <https://docs.espressif.com/projects/esp-idf/en/latest/esp32/api-reference/peripherals/gptimer.html>